

**WORKING INSTRUCTIONS
AND
ILLUSTRATED PARTS LIST**

**THE HOWARD
PATENT
ROTARY HOE "TEN"**

**ROTARY HOES, LTD.
STATION ROAD
EAST HORNDON
ESSEX**

**'Phone :
HERONGATE 96 and 26**

**Telegrams :
ROTOVATE BRENTWOOD**

**KEEP THIS BOOK IN A SAFE PLACE
ITS REPLACEMENT MAY BE DIFFICULT**

WORKING INSTRUCTIONS
AND
ILLUSTRATED PARTS LIST

THE HOWARD
PATENT
ROTARY HOE "TEN"

ROTARY HOES, LTD.
STATION ROAD
EAST HORNDON
ESSEX



THE ROTARY HOE "TEN"



This machine is a larger edition of the popular "Gem" and is designed to meet the requirements of the grower with a bigger area of land than the "Gem" owner. It is particularly suitable for orchardists and open-field market gardeners and is capable of filling the tillage requirements of the 20 acre holding.

The "Ten" is built with a standard cultivating width of 30" but where soil and other conditions permit their use, machines with a 36" width of cut can be supplied.

Built on the same sturdy lines as the "Gem" the Rotary Hoe "Ten" will give long and faithful service, and in order to assist users to get the best results from the implement the following directions on care and maintenance, together with a few practical hints on fault-finding are listed and should be closely studied.

THE ENGINE. The power unit is a 50° V-twin with a capacity of 1,300 c.c. Lubrication is on the dry sump principle and governed engine speed is 1,500 r.p.m.

On receiving delivery of a new machine check the engine carefully making sure that oil pipes have not been crushed or broken in transit. Also make sure that tap on oil feed pipe from tank to engine is turned on.

Starting up. Before starting up make sure that both gear levers are in their neutral positions, turn on petrol and flood carburettor and retard ignition by moving magneto control lever upwards. Open throttle slightly by raising throttle control lever (R.H. handle bar) and engage starting handle on starting dog. Now stand alongside machine facing engine and with the L.H. turn the exhaust valve lifting lever upwards. Swing the starting handle briskly and while still turning release the exhaust valve lever. As soon as engine has started advance ignition by moving magneto control lever downwards to its full extent. Do not forget to put starting handle back into its normal carrying position before commencing work.

COMMENCING WORK. When the engine is running satisfactorily, lift the clutch lever, situated under the left-hand handle bar, pull the travel gear lever into selected position, then pull the rotor gear lever into position, open the throttle lever fully (situated under the right-hand handle bar), and gently release the clutch.

CULTIVATION. For cultivating virgin soil or land tightly bound together with grass or roots, the best results are obtained by first cultivating shallow, just to take the surface off, leaving it for a few days and then cultivate to the required depth.

The low gear must be used when cultivating ground that is very hard or covered with heavy growths, which require to be thoroughly cut up, and the ground well pulverized. Second gear is used for all ordinary cultivation, and top gear for light cultivation, or running the machine to work. To get the required depth of tillage a special depth control skid is fitted, coupled to a depth control lever which, when moved up or down, varies the depth of tillage. Always work at the highest gear that gives the tilth required to avoid wastage of petrol, and avoid working the ground too fine.

GENERAL MAINTENANCE AND ADJUSTMENTS

ENGINE. Check valve tappet clearances occasionally and when adjustments are necessary make sure that tappet lock nuts are securely tightened. Tappet clearances should be .010" for exhaust valve and .008" for inlet valve.

THE OIL PUMP. This is located in the timing box cover plate and is of the reciprocating gear drive plunger type driven from the camshaft. It is of very simple construction and unlikely to give any trouble. Care should however be taken to see that the oil pump fulcrum pin (8455) is securely screwed home. The end of this pin is located in a helically cut groove in the pump plunger which while rotating is made to travel backwards and forwards to the limit of this groove. Should the fulcrum pin get lost or even loose the plunger ceases to function and the engine should not be run until the fault has been remedied.

ENGINE GOVERNOR. A centrifugal type governor is incorporated on the timing end of engine crankshaft and is totally enclosed within the timing cover. It is of simple construction and is entirely automatic in operation. As delivered from works governors are set to allow a maximum engine speed of 1500 r.p.m. and provided the manually operated throttle control lever is set at the fully open position the governor will maintain constant engine speed at all loads. Engine speed should not be altered except under expert advice. It is essential that the governor control slide and links should be oiled occasionally so that carburettor can respond freely to demands made on it by the Governor.

DIFFERENTIAL. The gear box is provided with a differential gear which makes turning on headlands a very simple matter. Operating in conjunction with the rotor gear is a differential locking device which gives the effect of a solid axle while cultivating. When rotor gear is put in neutral position (which is essential when turning) the differential gear is automatically unlocked.

MAGNETO. The magnetos fitted will give years of trouble free service, but to ensure that they do so, periodic check over is necessary. See that contact breaker arm is working freely and that gap between points is properly adjusted using the gauge on magneto spanner for this purpose.

CARBURETTOR. To adjust the carburettor, screw needle in jet bolt, upwards but not too tightly, then unscrew one and a half turns. Open throttle slightly, start engine and close throttle to stop screw. If necessary, adjust idling air adjusting screw until engine runs smoothly. Turn this

screw inwards to make the mixture richer and outwards for a lean mixture. Adjust main jet adjusting screw as lean as possible (by screwing upwards) to get quick and even acceleration and smooth running when throttle is operated.

It is sometimes necessary to open main jet screw when starting in cold weather, closing it as lean as possible to get economical working after engine warms.

To clean the carburettor jet, it is necessary to take out the main jet bolt through which the main jet adjusting screw operates. The idling jet is a very small hole drilled in the groove halfway up the jet bolt. It can be cleaned out with a fine wire.

ENGINE CLUTCH. The clutch is of a single fibre disc type, simple in operation and efficient in work. It should be adjusted with a little play on the lever so that the thrust bearing is free except when the hand lever is lifted; adjustment can be made by unscrewing the clutch connecting rod in the eyebolts on clutch fulcrum lever near the engine.

ENGINE OIL FILTER. When changing engine oil make it a routine job to clean filter at the same time. To extract the filter element from the tube remove oil pipe connection on front end and undo the brass caps at both ends and withdraw the filter and centre tube. Wash thoroughly in petrol or Kerosene and if the bag is damaged replace with a new one. When replacing filter element make sure that the brass caps and the oil pipe (return to tank) are securely tightened up.

AIR CLEANER. To ensure regularity in attending to the air cleaner make this job also a routine one when changing engine oil. To remove cleaner loosen the clamping nut on top of clamping bracket, push clamp to one side and leaving cover still connected to hose connection take air cleaner bodily from its platform. Separate the top from the bottom half of the cleaner and pour away the dirty oil in the reservoir and wash out all sediment in the bottom thoroughly. Then remove the serrated spring clip in filter container and carefully take out the horsehair and gauze filters and wash in petrol or kerosene. Next refill oil reservoir up to just **BELOW** the air intake pipe using oil which has been drained from engine oil tank. Put horsehair and gauze plates back into horsehair container making sure that perforated plate to which the zinc cone is attached is placed in the bottom with apex of cone downwards. Now place the two halves together (with cork washer between), replace cover and clamp back into position.

ROTOR FRICTION DRIVE. The flanges to which the rotor blades are bolted are driven direct from the main gear box through a metal-to-metal friction clutch similar to that on the road wheels and is adjusted by four half-inch nuts. This clutch is not intended to operate except when

the rotor blades strike a submerged object, and must be adjusted so that no slip takes place when working under ordinary conditions.

ROAD WHEELS. The road wheels are mounted on wheel hubs and frictionally held in position by clamping plate with four springs and nuts. These are adjusted so that the wheels have sufficient grip to pull the machine but will slip if they become jammed with an obstruction between wheel and gearbox.

MAINTENANCE OF HOE BLADES. It is essential that the cutting edge only should rub in the soil and the back have clearance. The blades are designed so that continual use in average soil tends to sharpen them, but if the machine is to be used on stony ground we suggest that two sets of hoe blades be kept and used alternatively keeping one set sharpened.

The efficiency of the machine depends largely on the condition of the hoe blades. If these get bent through striking solid obstacles in the ground and are not straightened up, they will require twice the power to drive, the quality of work will be poor and the blades will wear out quickly. Trouble will also be experienced with clogging under the shield: therefore a keen lookout should be kept for bent hoes, which should be straightened up as soon as noticed with the blade setting bar provided.

LUBRICATION. (*Also see Lubrication Chart.*)

For the Engine use good quality air cooled engine oil such as Castrol XL, Triple Shell (Summer) and Double Shell (Winter) or any similar good grade oil.


For the transmission we recommend Castrol Swanshot Shell Spirax Gear oil, or corresponding grades by other manufacturers.

ENGINE. Point 'A' on Chart. The oil compartment (front) of the fuel tanks has a capacity of approximately 3 pints but care should be taken to fill only up to within half-an-inch of the oil return pipe located inside tank under filter cap. Oil is gravity fed to the delivery end of the oil pump and forced under pressure into the big end bearings, being returned to tank via the filter by the suction end of pump. As a general practice oil should be renewed completely after every 36 hours of work but this period should be reduced to 24 hours when the machine is operating in very dusty conditions.

GEAR BOX—Point 'E' on Chart. Maintain the level as indicated on the uppermost mark on the dipstick, which is attached to the gas plug screwed into top of Gear Box. The clutch thrust race is located inside gear box and is lubricated by the constant swirl of oil maintained therein. Normally it should only be necessary to drain and renew oil in gear box after every hundred hours of work. This job is best carried out when

A ENGINE OIL.

E GEAR BOX (UNDER TANK)



BIRDS EYE VIEW OF
ROTEHO TEN.

CLUTCH UNDER.

THROTTLE UNDER.

OILING CHART

oil is warm and a good practice is to remove drain plug at the end of a day's work leaving the plug out all night. Capacity of gear box up to required level is about approximately $1\frac{1}{4}$ gallons.

ROTOR DRIVE DOG GEAR BOX—Point 'B' on Chart. Remove square headed gas plug and oil liberally with oil can daily.

ROTOR DRIVE CHAIN BOX—Point 'C' on Chart. Remove Gas plug on top of chain case cover and maintain level of gear oil up to lower mark on main gear box dipstick referred to above. Do not overfill as this may result in oil being forced on to the rotor friction clutch causing it to slip unnecessarily.

ROTOR STUB AXLE—Point 'D' on Chart. Remove round headed screw and fill cup located inside rotor tube with engine oil from oil can. It will generally be found that this supply is sufficient for 24 hours work and can be attended to when routine changing of engine oil is carried out.

In addition to the lubrication directions enumerated such points as the depth control pedestal to skid or wheel, slide bar of swinging handlebars and fulcrum levers of throttle and clutch controls should be oiled frequently with oil can to ensure free movement.

ATTACHMENTS AND EQUIPMENT

Following is a list of the various attachments which can be used with the Rotary Hoe Ten for mobile and stationary work.

MOBILE.

Furrowing Attachment.
Furrow Covering Attachment.
Picktine Rotor.

STATIONARY.

Machine Stand.
Power Take off Pulley.
Soil Shredder.

FITTING ATTACHMENTS.

The furrowing attachment is fitted in place of the depth control wheel or skid. Where the latter has been supplied as standard equipment it is used as the pedestal for the furrower. For machines where depth control **wheel** has been fitted the skid must be ordered in addition to the furrower body. When using furrower, the Rotor is put in gear so that the combined operations of cultivating and ridging are carried out simultaneously.

The furrow covering attachment is supplied complete with its own pedestal and it is fitted in the same way as the furrower. When in use the rotor should be **out of gear**, allowing the rotor to roll over the ground like a wheel.

Depth for both the above operations is controlled in the same way as for ordinary cultivations.

To fit picktine Rotor which is used for special work such as dealing with very hard soil conditions or pasture renovation, proceed as follows:

Remove all nuts and bolts holding the stub axle to the Rotor Support Bracket, Staytube and Rotor Shield, then remove the four Rotor Friction Drive Adjusting nuts and springs, by sliding the Rotor sideways it can be withdrawn. The Picktine Rotor is then fitted by reversing the operations above.

For all stationary work the Rotary Hoe must be mounted on the specially provided machine stand which should be ordered with either the Power Take Off Pulley or Soil Shredder.

NOTE.—The same stand is suitable for either purpose.

To fit the Machine Stand, place a strong wooden box under the engine silencer and lift machine clear of the ground by the handle bars, pivoting on the wooden box, the stand is then put in position so that Road Wheel Axle Bearing casting sits in the two "U" shaped arms provided on the stand. The machine is then lowered and the Road Wheels will be clear of the ground, the wooden box can now be removed. See that the machine is standing on the Depth Control Skid or Wheel, and that the weight is not on the Rotor. When using the Power Take Off the machine should be put in low gear to ensure that the oil circulates. **DO NOT PUT ROTOR IN GEAR** unless you are using the Soil Shredder. The Rotor should not be used when using Power Take Off only.


To Fit the Power Take Off remove the hinge bolt for the Starting Handle, remove the four set screws holding the Starting Dog Bearing Cover in place on the Gear Box Side Plate, and remove the Cover and Loose Dog. Assemble Power Take Off casting in place of the Bearing Cover, see that the Dogs in the bearing and the Power Take Off Shaft mesh, and replace the four set screws. Next insert the Starting Handle hinge bolt in the hole provided in the Power Take Off casting and tighten. After oiling the Power Take Off bearing behind the pulley it is ready for use.

To fit Soil Shredder remove the two end rotor blades near the Stub Axle and replace them with the Feeder Blades, next lift machine sufficiently high to pass the Shredder into position under the Rotor, lower machine, seeing that the lugs on the Shredder locate on the Staytube and Chain Case, tighten the clamping bolts and start work. The Machine Stand **must** be used with the Shredder as for all stationary work.

SPECIAL NOTE.

All references to left and right hand are to be read as from rear of machine looking forward.


Important. When ordering spare parts always quote the serial number of your machine which will be found stamped on main frame member in rear of fuel tank. This information will ensure correct parts being sent.



PART No.

DESCRIPTION OF PART.


T. 101	Main Frame for Swinging Handle Bars.
T. 102	Swinging Handle Bars.
T. 102a	Handle Bar Slide Bolts (2)
T. 102b	Handle Bar Slide.
T. 104	Handle Bar Pivot Block.
T. 121	Handle Grips (Pair).
T. 130	Road Wheel. Cast Iron. Cleated Type (state left or right-hand).
T. 130a	Road Wheels for Pneumatics. (State left or right-hand.)
T. 140	Road Wheel Hub.
T. 140a	Road Wheel Hub Keys. (2 per hub.)
T. 141	Road Wheel Hub Studs (8).
T. 142	Road Wheel Hub Stud Springs (8).
T. 150	Road Wheel Gear Selector.
T. 152	Road Wheel Gear Selector Arm.
T. 153	Rotor Gear Selector.
T. 154	Rotor Gear Selector Arm.
T. 160	Road Wheel Shaft Nut.
T. 162	Road Wheel Hub Disc. (pair.)
T. 169a	Petrol and Oil Tank.
T. 171	Oil and Petrol Drain Plug (2).
T. 172	Petrol and Oil Tank Caps (2).
T. 173	Petrol Pipe.
T. 174	Oil Pipe Tank to Engine.
T. 174a	Oil Pipe Return to Tank.
T. 174b	Oil Pipe Return from Engine.
T. 175	Petrol and Oil Tank Straps (pair).
T. 175a	Petrol and Oil Tank Strap Nuts (4).
T. 178	Air Cleaner Inlet Pipe Cap.
T. 180	Air Cleaner Horse Hair Container.
T. 180a	Air Cleaner Perforated Plate.
T. 180b	Air Cleaner Perforated Plate Base.
T. 181	Air Cleaner Cover.
T. 181a	Air Cleaner Hose Connection.
T. 182	Air Cleaner Horse Hair Container Cover Clip.
T. 183	Air Cleaner Clamp Screw.
T. 184	Air Cleaner Clamp.
T. 185	Air Cleaner Tank.
T. 186	Air Cleaner Tank Support Bracket.



PART NO.

DESCRIPTION OF PART.

T. 187	Exhaust Muffler Tube. (Centre.)
T. 188	Exhaust Valve Hand Lifting Lever.
T. 189	Exhaust Muffler End Plates (2).
T. 189a	Exhaust Muffler.
T. 190	Fly Wheel.
T. 190a	Fly Wheel Nut.
T. 190b	Fly Wheel Key.
T. 191	Fly Wheel Housing.
T. 192	Cooling Blast Shroud. (State left or right-hand.)
T. 193	Cooling Blast Shroud Base Plate. (State left or right-hand.)
T. 195	Engine Support Studs. 4 short 2 long.
T. 201	Clutch Housing Inspection Plate.
T. 211	Clutch Pins for Fly Wheel.
T. 220	Clutch Friction Fibre Plate.
T. 230	Clutch Friction Plate Loose.
T. 240	Clutch Shaft.
T. 240a	Clutch Plate Fixed.
T. 250	Clutch Bolts for Springs (3).
T. 255	Clutch Spring Bolt Distance Piece (3).
T. 260	Clutch Springs (3).
T. 261	Clutch Shaft Spigot Bearing. LS 5.
T. 262	Clutch Shaft Thrust Race. $W\frac{3}{4}$.
T. 288	Clutch Thrust Sleeve.
T. 290	Clutch Thrust Plate.
T. 291	Clutch Fulcrum Pawl.
T. 295	Clutch Shaft Bearing. MS 8.
T. 296	Clutch Shaft Gitseal.
T. 297	Clutch Shaft Gitseal Holder.
T. 298	Clutch Shaft Gitseal Holder Screws.
T. 299	Loose Hub Gear Outer Ball Bearing. XLS $1\frac{3}{4}$.
T. 299a	Loose Hub Gear Inner Ball Bearing XLS $1\frac{7}{8}$.
T. 300	Road Wheel Shaft Bearing. LS 12.
T. 300a	Road Wheel Shaft Bearing Stop.
T. 300b	Road Wheel Shaft Bearing Stop Screws.
T. 301a	Axle.
T. 301c	Axle Felt Seal.
T. 303	Bull Wheel.
T. 304	Wheel Pinions (6).
T. 304a	Wheel Pinion Studs (6).
T. 305	Loose Hub Gear Oil Seal.
T. 306	Road Wheel Shaft Gitseal.
T. 307	Loose Hub Gear.
T. 307a	Fixed Hub Gear.
T. 308	Wheel Hub.



PART NO.

DESCRIPTION OF PART.

T. 308a	Wheel Hub Nut.
T. 309	Wheel Hub Dust Cover.
T. 310	Wheel Hub Dust Cover Screws (3).
T. 311	Axle Washer.
T. 312	Axle Nut.
T. 313	Differential Lock.
T. 314	Differential Lock Ring.
T. 315	Differential Lock Pins (3).
T. 316	Differential Lock Pin Spacers (3).
T. 317	Differential Lock Ring Set Screws (3).
T. 318	Differential Lock Fork.
T. 319	Differential Lock Fork Trunnion.
T. 320	Fixed Hub Gear Rivets (6).
T. 321	Differential Lock Rod.
T. 322	Differential Quadrant.
T. 323	Differential Lock Quadrant Pin.
T. 334	Layshaft Gear Small.
T. 339	Layshaft Gear Large.
T. 341	Bull Pinion.
T. 349	Layshaft Nut.
T. 350	Layshaft.
T. 351	Layshaft Bearing, Right Hand LS 10.
T. 351a	Layshaft Bearing, Left Hand LS 8.
T. 352	Change Speed Pinions.
T. 363	Bevel Pinion.
T. 366	Bevel Crown Wheel.
T. 371	Low Gear Wheel.
T. 373	Starting Dog Loose.
T. 374	Starting Dog Bearing Housing.
T. 375	Starting Dog Bearing Housing Bolts (4).
T. 380	Starting Handle.
T. 381	Starting Handle Support Bracket.
T. 437	Starting Dog and Bearing.
T. 437a	Starting Dog and Bearing Circlip.
T. 438	Jackshaft.
T. 439	Rotor Sliding Dog.
T. 439a	Rotor Fixed Dog.
T. 451	Jackshaft Bearing MS 330.
T. 451a	Jackshaft Oil Seal Disc.
T. 452	Jackshaft Extension.
T. 453	Jackshaft Extension Housing.
T. 454	Jackshaft Extension Housing Studs (2).
T. 454a	Jackshaft Extension Housing Bolts (2).




456



458



460



464



465



466




457



468



481





473




472A


474



470




519




472




520




540



542



530




552



587




586




543

550




551B


451



M.S. 330




560




551



551A



585









589

PART NO.

DESCRIPTION OF PART.


T. 456	Dog Clutch Housing Cover.
T. 457	Dog Clutch Housing Set Screws (3).
T. 458	Dog Clutch Housing Cover Oiling Screw.
T. 459	Jackshaft Extension Bearing MS 11.
T. 460	Jackshaft Extension Sprocket.
T. 463	Oil Seal Disc for Road Wheel.
T. 464	Handle Bar Positioning Arm.
T. 465	Handle Bar Positioning Pin.
T. 466	Spring.
T. 468	Gear Control Quadrant.
T. 470	Gear Box.
T. 470a	Gear Box Gasket.
T. 471	Gear Box Side Plate.
T. 472a	Gear Box Side Plate Set Screws.
T. 473	Gear Box Inspection Plate.
T. 474	Gear Box Inspection Plate Gasket.
T. 475	Gear Box Inspection Plate Screws (4).
T. 481	Gear Change Shaft Bush.
T. 519	Rotor Drive Box Wearing Shoe.
T. 520	Rotor Drive Box Cover.
T. 520a	Rotor Drive Box Cover Gasket.
T. 530	Rotor Drive Box Back Plate.
T. 540	Rotor Drive Bearing Housing.
T. 542	Rotor Drive Bearing Dust Cover.
T. 543	Rotor Drive Wearing Plate (4 holes).
T. 550	Rotor Drive Shaft.
T. 551	Rotor Drive Chain.
T. 551a	Rotor Drive Chain Connecting Link.
T. 551b	Rotor Drive Shaft Bearing MS 330.
T. 552	Rotor Drive Spacing Sleeve.
T. 560	Rotor Drive Sprocket.
T. 585	Rotor Drive Chain Skid.
T. 586	Chain Skid Hinge Bolt.
T. 587	Chain Skid Positioning Screw.
T. 588	Rotor Drive Box Cover Set Screws.
T. 589	Staytube.




PART NO.

DESCRIPTION OF PART.

T. 600	Rotor.
T. 601	Rotor Drive Friction Plate.
T. 602	Rotor Drive Friction Stud Springs (4).
T. 603	Rotor Drive Studs (Friction) (4).
T. 604	Rotor Drive Friction Plate Stud Nuts (4).
T. 610	Rotor Friction Drive Disc.
T. 615	Rotor Drive Shaft Gitseal.
T. 630	Rotor Stub Axle.
T. 631	Rotor Stub Axle Bearing, MS 7.
T. 632	Rotor Stub Axle Bearing Cap.
T. 633	Rotor Stub Axle Dust Cover.
T. 634	Rotor Stub Axle Spacing Sleeve.
T. 635	Rotor Stub Axle Back Plug.
T. 636	Rotor Stub Axle Gitseal.
T. 637	Rotor Stub Axle Gitseal Holder.
T. 638	Rotor Stub Axle Oiling Screw.
T. 641	Rotor Shield Front.
T. 642	Rotor Shield Rear.
T. 643	Rotor Shield Hinge Bolts (2).
T. 644	Rotor Shield Adjusting Clamping Bolt (2).
T. 645	Rotor Shield Trailing Board.
T. 650	Rotor Support Bracket (Stub Axle End).
T. 658	Rotor Depth Control Wheel Outer Dust Cover.
T. 658a	Rotor Depth Control Wheel Inner Dust Cover.
T. 659	Rotor Depth Control Wheel Bush.
T. 660	Rotor Depth Control Wheel.
T. 661	Rotor Depth Control Wheel Axle.
T. 661a	Rotor Depth Control Wheel Axle Nut.
T. 662	Rotor Depth Control Wheel Bush Cap.
T. 662a	Rotor Depth Control Wheel Bush Cap Oiling Screw.
T. 663	Rotor Depth Control Wheel Arm.
T. 664	Rotor Depth Control Wheel Pedestal.
T. 666	Rotor Depth Control Wheel Pedestal Pin.
T. 667	Rotor Depth Control Socket Support to Frame (2).
T. 670	Rotor Depth Control Socket.
T. 671	Rotor Depth Control Lever
T. 674	Rotor Depth Control Socket Clip.
T. 675	Rotor Depth Control Lever Socket Clip Spring.
T. 676	Rotor Depth Control Lever Socket Clip Bolt.




PART NO.	DESCRIPTION OF PART.
T. 698	Handle Bar Clutch Hand Lever.
T. 702	Clutch Hand Lever to Clutch Rod.
T. 702a	Clutch Hand Lever Adjusting Link.
T. 703	Clutch Adjustment Trunnion Nut.
T. 710	Clutch Fulcrum.
T. 712	Handle Bar Clutch Arm.
T. 772	Change Speed Arm Eye Bolt.
T. 773	Rotor End Diff. Arm Eyebolt.
T. 780	Travel Gear Lever.
T. 781	Rotor Gear Lever.
T. 782	Travel Gear Control Rod.
T. 783a	Rotor Gear Control Rod.
T. 784a	Throttle Hand Lever to Throttle Arm Rod.
T. 785a	Throttle Arm to Carburettor Arm Rod.
T. 786a	Throttle Hand Control Lever.
T. 787a	Throttle Arm.
T. 789	Throttle Rod Trunnion.
T. 789a	Clutch Arm to Clutch Fulcrum Rod.
T. 790	Tool Box.
T. 820	Weed Cutter Blade, Left Hand.
T. 822	Weed Cutter Blade Right Hand.
T. 825	Weed Cutter Blade Bracket.
T. 880	Oil Filter Tube.
T. 881	Oil Filter End Caps (2).
T. 881a	Oil Filter Fibre Discs (2).
T. 882	Oil Filter Centre Tube.
T. 885	Oil Filter Tube Nipple.
T. 886	Oil Filter Connecting Union.
T. 887	Oil Filter Locating Washer.
T. 889	Oil Filter Bag Securing Discs (2).
T. 890	Oil Filter Bag.
T. 900	Rotor Hoe Blade, Right.
T. 900a	Rotor Hoe Blade, Left.
T. 915	Rotor Hoe Blade Bolts and Washers.
T. 916	Rotor Hoe Blade Drive End Flange Bolts.
T. 993	Blade Setting Bar.



600a




996



997




932




941



938



940




935



937




936




933




939




1001




951



1000




950a




950



1006




1005




1010



946




945



1009



1008



947

PART NO.

DESCRIPTION OF PART.

PARTS FOR PICK TYNE ROTOR.

- T. 600a Picktyne Rotor.
- T. 996 Picktyne Rotor Blade.
- T. 997 Lucerne Blade.

PARTS FOR POWER TAKE OFF.

- T. 932 Power Take Off Spacing Collar.
- T. 933 Power Take Off Housing.
- T. 934 Power Take Off Bearing Oil Screw.
- T. 935 Power Take Off Bearing Dust Cover.
- T. 936 Power Take Off Shaft Bearing LS 9.
- T. 937 Power Take Off Shaft.
- T. 938 Power Take Off Shaft Nut.
- T. 939 Power Take Off Pulley Key.
- T. 940 Power Take Off Pulley.
- T. 941 Power Take Off Starting Handle.

PARTS FOR MACHINE STAND.

- T. 945 Machine Stand.
- T. 946 Machine Clamping Bar.
- T. 947 Machine Clamping Studs.
- T. 948 Machine Adjusting Screw.

FURROWING AND COVERING ATTACHMENT.


- T. 950 Mouldboard Stem and Skid.
- T. 950a Mouldboard.
- T. 951 Furrow Covering Tool.

SOIL SHREADER.


- T.1000 Soil Shreader.
- T.1001 Feeder Blade.
- T.1002 Soil Screen.

PARTS FOR ROLLER ATTACHMENT.


- T.1005 Roller.
- T.1006 Roller Axle.
- T.1007 Roller Axle Nut (2).
- T.1008 Roller Axle Bush (2).
- T.1009 Roller Side Frames Right and Left Hand.
- T.1010 Roller Pedestal.
- T.1011 Roller Pedestal Bolts (2).



8010 R.H. 8011 L.H.



8020 R.H. 8030 L.H.




8040 8041



8050



8035



8060




8045



8080



8090



8120
8125



8070




8150



8130




8100



8170



8160



8140



8110



8200




8180



8181



8182




8265



8210



8230



8220



8260



8261




8290




8240



8250




8280



8310



8320



8270

PART NO.

DESCRIPTION OF PART.


BE.8010	Cylinder Barrel Right Hand.
BE.8011	Cylinder Barrel Left Hand.
BE.8020	Valve Chamber Right Hand.
BE.8030	Valve Chamber Left Hand.
BE.8035	Spark Plug KLG (2).
BE.8040	Cylinder Head Left Hand.
BE.8041	Cylinder Head Right Hand.
BE.8045	Cylinder Head Engine Timing Plug.
BE.8050	Cylinder Head Gasket (2).
BE.8060	Valve Chamber Gasket (2).
BE.8070	Cylinder Head Holding Down Bolts (8).
BE.8080	Cylinder Head Bolts.
BE.8090	Induction Pipe.
BE.8100	Induction Pipe Nut (2).
BE.8110	Induction Pipe Clamping Cone (2).
BE.8120	Exhaust Valve (2).
BE.8125	Inlet Valve (2).
BE.8130	Valve Guide (4).
BE.8140	Valve Springs (4).
BE.8160	Valve Spring Collets (4).
BE.8150	Valve Spring Cups (4).
BE.8170	Valve Spring Upper Cover (4).
BE.8180	Valve Spring Bottom Cover (4).
BE.8181	Valve Spring Locking Nut (4).
BE.8182	Valve Cover Centring Ring (4).
BE.8200	Tappet Caps (4).
BE.8210	Tappet Cap Lock Nut (4).
BE.8220	Tappet (Inlet Long) (2).
BE.8230	Tappet (Exhaust Short) (2).
BE.8240	Tappet Guide (Inlet Long) (2).
BE.8250	Tappet Guide (Exhaust Short) (2).
BE.8260	Cylinder Base Stud (8).
BE.8261	Cylinder Base Stud Nut (8).
BE.8265	Cylinder Base Gasket (2).
BE.8270	Crankcase Drive Side.
BE.8280	Crankcase Timing Side.
BE.8290	Crankcase Flanging Bolts (2).
BE.8310	Timing Cover and Oil Pump Body.
BE.8311	Timing Cover and Oil Pump Body Gasket.
BE.8320	Timing Cover and Oil Pump Body Screws.



PART NO.

DESCRIPTION OF PART.


BE.8330	Timing Cover Countersunk Screw.
BE.8340	Exhaust Valve Lifting Spindle (2).
BE.8350	Exhaust Valve Lifting Arm (2).
BE.8360	Exhaust Valve Lifting Lever Disc.
BE.8370	Exhaust Valve Lift Arm Conn. Rod (2).
BE.8380	Breather Core.
BE.8390	Breather and Crankcase Suction Body Core Plugs.
BE.8400	Breather Pipe.
BE.8411	Breather Ball Valve.
BE.8420	Breather Valve Spring.
BE.8430	Crankshaft Oil Feed Screw Valve Body.
BE.8431	Crankshaft Oil Feed Screw Valve Body Plug.
BE.8432	Crankshaft Oil Feed Screw.
BE.8433	Crankshaft Oil Feed Screw Locknut.
BE.8434	Crankshaft Oil Feed Screw Ball Valve.
BE.8435	Crankshaft Oil Feed Screw Ball Valve Spring.
BE.8450	Oil Pump Plunger.
BE.8451	Oil Pump Drive Gear.
BE.8455	Oil Pump Plunger Set Screw.
BE.8460	Oil Pump Drive Pinion.
BE.8461	Oil Pump Intermediate Gears.
BE.8470	Oil Pump Body Plug.
BE.8465	Oil Pump Intermediate Gear Spindle.
BE.8500	Camshaft.
BE.8501	Camshaft Thrust Ball.
BE.8502	Camshaft Thrust Ball Spring.
BE.8510	Camshaft Key.
BE.8520	Camshaft Bearing.
BE.8530	Camshaft Magneto Bearing.
BE.8540	Camshaft Oilseal.
BE.8545	Camshaft Oilseal Holder.
BE.8550	Camshaft Bearing Set Screws (8).
BE.8556	Oil Pump Plunger Screw Fibre Washer.
BE.8562	Magneto Control Hand Lever.
BE.8563	Magneto Control Hand Lever Bracket.
BE.8568	Magneto Control Hand Lever Connecting Rod.
BE.8570	Magneto Platform.
BE.8575	Magneto Platform Screws (4).
BE.8591	Magneto Coupling Body Camshaft Half.
BE.8592	Magneto Coupling Flange Locking Plate.
BE.8593	Magneto Coupling Flange Drive.
BE.8594	Magneto Coupling Flange Screws.
BE.8601	Magneto Flange.
BE.8611	Magneto Laminated Coupling.
BE.8640	Crankcase Oil Suction Pipe Body.
BE.8650	Crankcase Oil Suction Pipe to Pump.
BE.8670	Oil Pressure Pipe to Crankshaft.
BE.8675	Oil Feed Pipe for Cylinder Wall Screw.
BE.8680	Oil Feed Cylinder Wall Screw.



8760



8700



8770




8800



8780




8820



8710



8790



8720



8870




8850



8810



8830



8730




8860



8890



8861



8900



8840




8910



8880



8940



8920



8930



8740



8725




8950



8960




8986



8750



8984




8987



8988



8988A



8985



8989



8988B




8991




8992




8999A



8999



8980



9000




9020



9010



9030




8993

PART No.

DESCRIPTION OF PART.

BE.8700	Piston (2).
BE.8710	Piston Ring (8).
BE.8720	Gudgeon Pin (2).
BE.8725	Gudgeon Pin Circlip (4).
BE.8730	Connecting Rod (2).
BE.8740	Connecting Rod Top End Bush (2).
BE.8750	Connecting Rod Bottom End Bearing (2).
BE.8760	Flywheel Timing Side.
BE.8770	Flywheel Drive Side.
BE.8775	Flywheel Scraper (2).
BE.8780	Crankshaft Timing Side.
BE.8790	Crankshaft Timing Side Key.
BE.8800	Crankshaft Timing Side Nut.
BE.8810	Crankshaft Timing Gear.
BE.8820	Crankshaft Timing Gear Cone.
BE.8830	Crankshaft Timing Gear Cone Key.
BE.8840	Crankshaft Timing Gear Cone Nut.
BE.8850	Crankshaft Timing Side Ballbearing.
BE.8860	Crankshaft Timing Side Oilseal Disc (Large).
BE.8861	Crankshaft Timing Side Oilseal Disc (Small).
BE.8870	Crankpin.
BE.8880	Crankpin Key.
BE.8890	Crankpin Flywheel Cone.
BE.8900	Crankpin Flywheel Cone Key.
BE.8910	Crankpin Nut.
BE.8915	Crankpin Nut Locking Screw.
BE.8920	Crankshaft Drive Side.
BE.8930	Crankshaft Drive Side Nut.
BE.8940	Crankshaft Drive Side Key.
BE.8950	Crankshaft Drive Side Ballbearing.
BE.8960	Crankshaft Drive Side Oilseal.
BE.8980	Magneto.
BE.8984	Governor Control Fork.
BE.8985	Governor Control Fork Spindle.
BE.8985a	Governor Control Fork Spindle Washer.
BE.8986	Governor Control Fork Arm.
BE.8987	Governor Spring.
BE.8988	Governor Spring Connecting Sliding Collar.
BE.8988a	Governor Spring Control Sliding Collar Ballbearing.
BE.8988b	Governor Spring Control Sliding Collar Ballbearing Wearing Plate.
BE.8989	Governor Control Rod to Fulcrum Arm .
BE.8991	Governor Control Rod Trunnion Nut.
BE.8992	Governor Control Carburettor Spring.
BE.8993	Governor Induction Pipe Fulcrum to Carburettor Rod.
BE.8999	Governor Induction Pipe Fulcrum.
BE.8999a	Governor Induction Pipe Fulcrum Set Screw.
BE.9000	Governor Throttle Slide.
BE.9010	Governor Weights (2).
BE.9020	Governor Weights Pin (2).
BE.9030	Carburettor Elbow.



**OTHER PRODUCTS MANUFACTURED
BY US INCLUDE**

THE ROTARY HOE "GEM" 6 h.p.

**THE ROTARY HOE ATTACHMENT
for FORDSON TRACTOR, including
models for FORDSON "MAJOR"**

**THE "ROTEHO" TRENCH DIGGER
also**

1, 5, & 15 Ton RATCHET JACKS

Write for particulars to :

**ROTARY HOES, LTD.
EAST HORNDON
ESSEX**